

## Fastening Walls, Day 1

### Instructions:

#### Exterior Walls

**Step 1:** Align wall to caulk line, fasten with Remington Gun, starting from corner or panel joint nearest to previously attached panel. Place only enough concrete nails to prevent wall from moving until concrete screws are installed (**typically no more than 2-3 per panel**)

**Step 2:** With concrete drill, drill hole through bottom of wall into concrete, making sure hole is deeper than concrete screw. Holes must be within 12 inches of each end of a panel section and no more than 4 feet apart (**typically no more than 3-4 per panel**)

**Step 3:** Using impact driver, drive in concrete screws until secure.

#### Interior Walls

**Step 1:** Using caulk gun, apply heavy bead of construction adhesive to slab inside caulk lines where wall will go (**Do Not apply adhesive in doorways**)

**Step 2:** Place wall in position and Fasten with Remington gun, working from one end of wall to the other end. Concrete nails must be within 12 inches of each end of a panel section or doorway and no more than 4 feet apart. (**Do Not nail in doorways**)

