

Interior Door Install

Overview: A door crew should be 2 people; if you have an additional trim gun, a second crew can start in a different part of the house.

Start in one of the back bedrooms and do all of the doors in that room, then move on to another bedroom – the trim crew can then get started behind you.

Safety Tips: Do not operate power tools without instructions from staff or SOS

Safety glasses should be worn at all times while using the nailing gun.

Do not shoot the nailing gun when someone else is standing in the line of the shot.

Always disconnect the air hose when clearing a jammed nail in the gun.

Tools:

1 each

Finish nailing gun
air compressor and air hose
4' level
Fine-tooth saw or sharp razor knife

2 each

Scrap riser blocks, 4-6 inch pieces of base molding (1/2" for carpet)

Materials: Interior doors per house plan
wood shims

2 1/2 inch 15 gauge finish nails for finish

