

Standing Walls, Day 1

Instructions:

- Step 1: Begin at back left corner of house with 2 exterior panels to form the corner
- Step 2: Install exterior walls with OSB sheathing facing out, align inside of walls with chalk marks (one panel will have OSB extended to overlap the edge of the other panel)
- Step 3: Install exterior walls, working towards front of house
- Step 4: Attach interior walls to slab, starting where they connect to exterior walls
- Step 5: Locate the shower/tub in the bathroom opening before installing all surrounding interior walls
- Step 6: Continue installing exterior and interior walls, working in a counter-clockwise direction
- Step 7: Install 2 exterior panels forming back right corner last

